


BRAKE

GENERAL MAINTENANCE

1. INSPECT BRAKE LINES AND HOSES

HINT:

Work in a well-lighted area. Turn the front wheels fully to the right or left before beginning the inspection.



- (a) Using a mirror, check the entire circumference and length of the brake lines and hoses for:

- Damage
- Wear
- Deformation
- Cracks
- Corrosion
- Leaks
- Bends
- Twists

- (b) Check all the clamps for tightness and the connections for leakage.
- (c) Check that the hoses and lines are not near sharp edges, moving parts or the exhaust system.
- (d) Check that the lines are installed properly and pass through the center of the grommets.

2. INSPECT FRONT BRAKE

- (a) Check the front brake pads and discs (see page [BR-42](#)).

3. INSPECT BRAKE LININGS AND DRUMS

- (a) Check the brake linings and drums. Also check the brake linings of the parking brake.